




## Dowel Screw (Hanger Bolt) with metric and wood thread, standard type

Also known as hanger bolts. A bolt with a wood thread at one end and a machined metric thread at the other, designed to be driven into a pre drilled pilot hole. Ideal for suspending sheet metal from wooden structures. Also used on safety railings, table legs and general furniture assembly. Some sizes include a central flat or hex drive section: please see the data sheet for more information.



d	l	l1	l2	d1	s	drive present
<b>M6</b>	50	20	30	6	-	no
<b>M6</b>	60	20	30	6	-	no
<b>M6</b>	80	30	30	6	-	no
<b>M6</b>	90	20	30	6	-	no
<b>M6</b>	100	30	30	6	-	no
<b>M6</b>	120	30	30	6	-	no
<b>M6</b>	140	30	30	6	-	no
<b>M6</b>	160	30	30	6	-	no
<b>M6</b>	180	30	30	6	-	no
<b>M8</b>	50	20	30	8	-	no
<b>M8</b>	60	25	35	8	-	no
<b>M8</b>	70	30	40	8	-	no
<b>M8</b>	80	30	45	8	-	no
<b>M8</b>	90	30	40	8	6	batch dependent
<b>M8</b>	100	40	40	8	6	batch dependent
<b>M8</b>	110	40	50	8	6	batch dependent
<b>M8</b>	120	50	50	8	6	batch dependent
<b>M8</b>	130	50	-	8	6	batch dependent

<b>d</b>	<b>l</b>	<b>l1</b>	<b>l2</b>	<b>d1</b>	<b>s</b>	<b>drive present</b>
<b>M8</b>	140	50	45	8	6	batch dependent
<b>M8</b>	150	50	-	8	6	batch dependent
<b>M8</b>	160	50	50	8	6	batch dependent
<b>M8</b>	180	20	50	8	6	batch dependent
<b>M8</b>	200	50	-	8	6	batch dependent
<b>M10</b>	60	20	-	10	8	yes
<b>M10</b>	80	20	50	10	8	yes
<b>M10</b>	90	20	-	10	8	yes
<b>M10</b>	100	30	60	10	8	yes
<b>M10</b>	110	40	-	10	8	yes
<b>M10</b>	120	50	60	10	8	yes
<b>M10</b>	130	40	-	10	8	yes
<b>M10</b>	140	50	55	10	8	yes
<b>M10</b>	150	40	-	10	8	yes
<b>M10</b>	160	50	60	10	8	yes
<b>M10</b>	180	50	60	10	8	yes
<b>M10</b>	200	50	60	10	8	yes
<b>M12</b>	80	20	60	12	10	no
<b>M12</b>	100	25	-	12	10	yes
<b>M12</b>	110	40	-	12	10	yes
<b>M12</b>	120	40	55	12	10	yes
<b>M12</b>	130	40	-	12	10	yes
<b>M12</b>	140	40	-	12	10	yes
<b>M12</b>	150	40	-	12	10	yes
<b>M12</b>	160	80	60	12	10	yes
<b>M12</b>	180	40	-	12	10	yes
<b>M12</b>	200	40	-	12	10	yes
<b>M12</b>	300	150	-	12	10	yes